


Quick Start Installation Guide



RA1-150.2 RA1-280.4 RA1-300.1 RA1-750.1 RA1-710.5

Before you start



CAUTION



Many new and factory radios require a reset code when disconnected from battery power. This is an anti-theft feature. Before unplugging power, you must determine if your radio/source unit requires a reset code. Check the operation manual for your vehicle or contact the dealer.

Congratulations on your choice of a MBQuart amplifier. This "Quick Start Installation" guide is meant to help you "hook up" and play music. For more detailed information, on system setting, speaker and subwoofer configuration and full specifications by model please visit our website at www.MBQuart.com

Power cable size


It is critical to use the proper power and ground cable. Select the size listed here for your amplifier model. Always use high quality copper cable.

| Model | Fuse Size | Cable Size |
|-----------|--------------|---|
| RA1-150.2 | 20a External | |
| RA1-280.4 | 40a External | 400000000000000000000000000000000000000 |
| RA1-300.1 | 40a External | 4ga |
| RA1-750.1 | 80a External | |
| RA1-710.5 | 80a External | |
| | | |

Power cable size and fuse size based on a 17ft power (B+) (OFC) cable length and 18-inch ground (OFC) oxygen free cable.


Any other lengths used please consult a certified professional installer.

Installation




Place terminal in a secure position so that it won't accidentally contact the negative battery post

Terminal




2 Run Cables

Properly route power, speaker and RCA cables through the vehicle.



3 Mount Amplifier

Choose a mounting location that will provide adequate air ventilation. Mount the amplifier to a secure surface. Do not mount the amplifier upside down.









The chassis ground connection is critical to the performance of the amplifier. Choose a location that is close to the amplifier. Completely scrape away the paint and use a nut and bolt if possible.

DO NOT USE AN EXISTING FACTORY BOLT!




5 Negative Power Connection

Attach the chassis ground cable to the amplifier negative terminal. It is important to make sure this connection is very tight.




Remote Turn-on Connection

Attach the remote turn on wire to the amplifier remote output of the source unit.




Positive Power Connection

Attach the main power cable to the amplifier +12V. The cable must run directly to the battery and be properly fused and be very tight.



8 Signal Input Connection

Connect the RCA cables to the INPUT connectors.



g Level Control




Turn the LEVEL control completely counter-clockwise to minimum.





10 Positive Battery Connection


Connect the power cable to the positive battery terminal. The power cable must be fused within 18 inches of the battery terminal.






Be prepared to disarm your vehicle's alarm and to enter your radio / source unit code.





Re-connect the negative battery terminal making sure it is securely tightened.




Common System Setup

2ch - Full Range

CROSSOVER






4ch - Full Range

Set INPUT MODE switch to 4CH. Set CH3&4 LOW PASS MODE.






4ch - Mixed Mono

Set INPUT MODE switch to 4CH. Set CH3&4 LOW PASS MODE.






Mono

SUBSONIC FREQUENCY SUB SONIC LOW PASS FREQUENCY








5 ch

Set INPUT MODE to 5CH.
Set CH1&2 and CH3&4 CROSSOVER switch to HP.





Setup



Open Control Panel To gain access to the RA1 amplifier series top mount setting control panel carefully remove the four screws and lift the face plate up.

When you're finished with the control panel mindfully put the face plate back together with the four screws. Make sure not to over tighten.



B Settings

The illustrations below describe the various controls. Refer to the illustration that matches your amplifier.

1 LEVEL Adjustment

The level control purpose is to match the output of your source signal to the amplifier. Refer to the section C for detailed instructions.

2X-OVER Switch

This switch will set the amplifier to have a full frequency output or to filter out high or low frequencies.

3 Frequencies Adjustment

The Low Pass Filter will cut off the frequencies above the setting. The High Pass Filter will cut off the frequencies below the setting.

4 SUBSONIC Switch

The Subsonic Switch will cut off the frequencies below the setting.


(5) BASS BOOST




The Bass EQ control will increase the power output at 45Hz for more pronounced bass. Exercise caution when using this control. Increase the level in small amounts until distortion is noticed, then back off a little.


RA1-300.1 / RA1-750.1












RA1-710.5





This is a critical step to insure your amplifier is properly adjusted to match the signal output level of your source unit.





THIS IS NOT A VOLUME CONTROL!

- If possible, with the source unit off, confirm that the primary volume control is turned down (counter clockwise).
- Turn on the source unit (CD, or MP3 player). Re-confirm that the volume is turned down. Make sure the source unit controls; balance, fader, bass and treble are all set to center or "0" adjustment. Make sure that the green LED on the end of the amplifier is illuminated.
- Play a clean musical selection of which you are very familiar. CD is preferred.
 Do not use radio signals for level setting. Hit play and start turning the volume of the source unit up.
- Stop increasing the source unit volume when you reach 3/4 (about 75%) or until
 you hear speakers begin to slightly start producing distortion.
- Increase the amplifier gain (clockwise) until distortion is heard, then back the level down (counter clockwise) until the distortion is eliminated. Small adjustments may need to be made to balance the levels of multiple amplifiers.



Some models include a bass remote. Avoid adjusting the bass remote while operating vehicle.





REM turn on SIGNAL SENSE ON, High level input DC turn on



REM TURN ON / DC SENSE ON SWITCH

There are two methods of switching the amplifier on and off. Select the appropriate position suited for your application.

REM TURN ON

This will turn on the amplifier when a +12v switched power typically from a source unit, is connected to the Amp Turn on - BLUE wire on the main power connection harness.

DC SENSE

The DC SENSE is for use with the source units that do not offer RCA outputs.



NOTE - If the RCA's are plugged into the amplifier and the TURN ON MODE is in the DC ON position, the amplifier will NOT turn on. Please re-read this document or hire a professional installer.



WARRANTY

Maxxsonics USA Inc. warrants this product, to the original consumer purchaser, to be free from defects in material and workmanship for a period of one (1) year from the date of purchase. Maxxsonics USA Inc. will, at it's discretion, repair or replace defective products during the warranty period. Components that prove to be defective in materials and workmanship under proper installation and use must be returned to the original authorized Maxxsonics USA Inc. retailer from where it was purchased. A photocopy of the original receipt must accompany the product being returned. The costs associated with removal, re-installation and freight are not the responsibility of Maxxsonics USA Inc. This warranty is limited to defective parts and specifically excludes any incidental or consequential damages connected therewith. To view the full warranty, please visit the website.

MBQuart products are designed and engineered in the USA by

MAXX50NICS

MBQUARTI

Reference RA1-150.2

150 Watt 2-Channel Amplifier

| English | Spanish | | |
|---|-----------------------------------|--|--|
| Model | Modelo | | |
| 1-Ohm | 1 Ohmio | | |
| 2-Ohm | 2 Ohmio | | |
| 4-Ohm | 4 Ohmio | | |
| Mono Bridged @ 4-Ohms | @ de 4 Ohmios Puente Monoaura | | |
| Frequency Response | Respuesta de frecuencia | | |
| Signal to Noise Ratio | Señalar a la Proporción del Ruido | | |
| THD% | La Deformación Armónica total % | | |
| Variable Hi-Pass | La variable de Pasa Alto | | |
| Bass Boost | Empuje Bajo | | |
| Specifications Subject To Change Without Notice | | | |

| French | |
|-----------------------------------|-----------|
| Model | RA1-150.2 |
| 10hm | N/A |
| 2 Ohm | 2 x 100w |
| 4 Ohm | 2 x 50w |
| Mono Enjambé @ de 4 Ohms | 1 x 200w |
| Réponse de fréquence | 10-35Hz |
| Signaler à la Proportion de Bruit | 101dB |
| La Déformation Harmonique totale% | .09% |
| La variable Haute Passe | 10-250Hz |
| Poussée Basse | 0-9dB |





MARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

↑ ADVERTENCIA: Cáncer y Daño Reproductivo - www.P65Warnings.ca.gov

AVERTISSEMENT: Cancer et Troubles de l'appareil reproducteur - www.P65Warnings.ca.gov

MBQUARTI

Reference RA1-750.1

750 Watt Mono-Block Amplifier

| English | Spanish |
|--------------------------|-----------------------------------|
| Model | Modelo |
| 1-Ohm | 1 Ohmio |
| 2-Ohm | 2 Ohmio |
| 4-Ohm | 4 Ohmio |
| Frequency Response | Respuesta de frecuencia |
| Signal to Noise Ratio | Señalar a la Proporción del Ruido |
| THD% | La Deformación Armónica total % |
| Variable Low-Pass | La variable de Pasa Bajo |
| Variable Subsonic Filter | Filtro Subsónico variable |
| Bass Boost | Empuje Bajo |

| RA1-750.1 |
|----------------------|
| 1 x 750w |
| 1 x 500w |
| 1 x 300w |
| 25Hz-250Hz |
| 99dB |
| .07% |
| 50-250Hz |
| 25Hx Fixed 0-12db |
| |

Specifications Subject To Change Without Notice



▲ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

ADVERTENCIA: Cáncer y Daño Reproductivo - www.P65Warnings.ca.gov

AVERTISSEMENT: Cancer et Troubles de l'appareil reproducteur - www.P65Warnings.ca.gov