## KENWOOD

# **CA-HRN14UT**

REAR SPEAKER HARNESS DESIGNED AND ENGINEERED FOR 2014-UP HARLEY-DAVIDSON® ULTRA MOTORCYCLES

#### **INSTRUCTION MANUAL**

JVCKENWOOD Corporation

## **Important Notes**

©2023 JVCKENWOOD Corporation. All Rights Reserved. KENWOOD® and eXcelon® are registered trademarks of JVCKENWOOD Corporation. Harley-Davidson®, Electra Glide®, Road Glide®, Street Glide®, Ultra Classic®, Tri Glide®, CVO™, Screamin Eagle® and Tour-Pak® are trademarks or registered trademarks of Harley-Davidson, Inc. and/ or its affiliates and if used or implied are for reference only. There is no affiliation between Harley-Davidson, Inc. and/or its affiliates. All other trademarks are the property of their respective owners. Specifications subject to change without notice.

Take the time to read through this instruction manual.

Familiarity with installation and operation procedures will help you obtain the best performance from your new product.

### Installation procedure

1. You will see that one end of this harness has two 4-pin connectors. One of these white 4-pin plugs will plug into the "amplified out" on the amp that will power the rear speakers. The amplifier comes with a short harness with a black 8-pin plug and two 4-pin blue plugs. Plug the 8-pin black plug into the amplifier's input that will power the rear speakers. The second 4-pin plug marked "rear in" on the rear speaker harness will plug into one of the blue 4-pin connectors, noting they will only go in one way.

2. The harness that will run the rear speakers will pass under the inner fairing on the clutch side of the bike. Loosen the tank's "chrome console" and run the wires up and over the gas tank, but under the tank's chrome console. There is a provision on the front of the console for wires to pass under it allowing the power harness to run on the brake side of the filler spout and the rear speaker harness to run on the clutch side of the spout.

NOTE: Although not necessary, the power and rear harnesses can go under the gas tank if you choose to remove and re-install the tank. With the tank removed you will see a factory wire channel where wires pass along the bike's frame. Removing the top of the channel will allow for the power and rear speaker harness to be safely run under the tank to the battery area. When reinstalling the top of the channel take care not to pinch any wires along the edges of the channel.

3. Just behind the threaded insert that holds the seat bolt on the back fender, you will see a large factory wire plug. One side of the plug has wires that go to each rear speaker pod. Separate this large factory plug. One plug from the KENWOOD rear harness will plug into each side of the factory plug just separated. They will only go together one way.

For updated information (the latest Instruction Manual, etc.), please visit the following website:



https://manual.kenwood.com/en\_contents/search/