

POWER

Remove Aluminum Trim Ring Mounting Screws and Set Aside

Place Protective Grille Onto Subwoofer. Align Notches In Grille with Trim Ring Mounting Holes

Place Trim Ring Over Protective Grille and Attach with Mounting Screws



1010-58892-02

T1SG-12



©2014 Rockford Corporation. All Rights Reserved. ROCKFORD FOSGATE and associated logos where applicable are registered trademarks of Rockford Corporation in the United States and/or other countries. All other trademarks are the property of their respective owners. Specifications subject to change without notice.

T1SG-12
S.N.

rockfordfosgate.com