BBBSS AUDIO SYSTEMS

BE9ACP USER'S MANUAL BLUETOOTH[®] | 340 WATTS | MP3-COMPATIBLE DIGITAL MEDIA AM/FM RECEIVER FEATURING 9" (229 mm) CAPACITIVE TOUCHSCREEN AND MULTICOLOR ILLUMINATION OPTIONS





Thank you for Choosing Boss Audio Systems!

IMPORTANT! Fill Out And Keep For Your Records.

$\widehat{1}$	IMPORTANT	
	Record the serial number of the product:	
	Model:	
	Serial Number:	
	Date of Purchase:	
	The serial number is located on the top part of the chassis.	

Contents

Contents	2
Notes	4
Cautions	5-7
About this Manual	7
California Prop. 65	7
Basic Product Operation	8
What comes in the box	8
Product Basics	9-16
Unit Installation	11
Operation instruction	12
Display screen disassembly instructions.	13
Using and Caring for the Touchscreen	14
Product Setup	15
Navigating the Menus	16
Apple CarPlay	17
Warnings	17
Using CarPlay	18

Gestures & Control	17
CarPlay Display	18
Disable Apps	18
Android Auto	19
Warnings	19
Using Android Auto	19
Bluetooth [®]	20
Cautions	20
Setup & Connections	20
Phonebook	20
Device Status	20
Calling	21
History	21
Private Mode	21
Audio	22
Track Control	22

Media Player Source Switching22	
Media23	
Warnings23	
USB Playback23	
Navigating Menu23	
Photos23	
Radio24	
Display Overview24	
Display Overview24 Controls24	
Controls24	
Controls24 Tuning	

Contents

AV IN25
Playback25
Camera25
Warnings25
Reverse View25
General Settings
Cautions26
System Language26
Time Zone26
Date & Time26
Auto Adjust Daylight Saving26
System Tone26
Power Off Delay26
Parental Disc Lock26
Audio27
EQ27
Balance/Fader27
Subwoofer27
Loudness27
Internal Amp27
Volume27
Source level27

Display Settings28	Conne
Illumination Control	Caution
Gamma28	Power
LED Touch Buttons28	
LED Animation	Speake
Bluetooth® Settings 29	Audio
Device Name29	Camer
Camera29	Parkin
Rear Camera input29	Hands-
Front Camera input29	Troub
Rear View pelay29	Speci
Radio Settings 29	-
Region29	
RBDS29	
Alternative Frequency (AF)	
Traffic Announcement (TA)29	

Connections		
Cautions & Warnings)-35	
Power/SWC	.30	
Speaker	31	
Audio Pre-amp/AV IN/ Radio	32	
Camera/USB/MIC	33	
Parking Brake	34	
Hands-free Mic	35	
Troubleshooting	.36	
Specifications	.38	

Important

This symbol with "WARNING" is intended to alert the user to the presence of critical instructions/procedures. Failure to observe the instructions/procedures can result in injury, death, damage to the product and/or property.



This symbol with "CAUTION" is intended to alert the user to the presence of important instructions/procedures. Failure to observe the instructions/procedures can result in injury or damage to the product and/or property.







Use of the Apple CarPlay logo means that a vehicle user interface meets Apple performance standards.

Apple is not responsible for the operation of

this vehicle or its compliance with safety and regulatory standards. Please note that the use of this product with iPhone or iPod may affect wireless performance.

ipone is trademark of Apple Inc., registered in the U.S. and other countries.

Apple CarPlay is a trademark of Apple Inc. Android Auto is a trademark of Google LLC. The *Bluetooth*[®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Boss Audio Systems is under license. Other trademarks and trade names are those of their respective owners

Caution

Precautions

BE SURE TO OBSERVE THE FOLLOWING GUIDELINES: Do not turn up the volume so high that you can't hear what's around you.

Use caution or temporarily discontinue use in potentially hazardous situations.

Do not operate mobile video equipment while driving a motorized vehicle – safe driving and safety consideration of others should always be your highest priority.

Set your volume control at a low setting, then slowly increase the sound until you can hear it comfortably without distortion, or ear discomfort.

In the event you should notice smoke, strange noises or odor from this product, or any other abnormal signs, immediately turn off the power and consult your dealer or the nearest authorized BOSS AUDIO SYSTEMS Service Center.

Using this product in this condition may result in permanent damage to the system.

Installation Precautions

Boss Audio Systems does not recommend to install the product yourself.

We recommend to have it professionally installed by a certified professional.

Always consult with a professional installer.

Do not attempt to install or service this product by yourself. Installation or servicing of this product by persons without professional training and experience in electronic equipment and motorized vehicle accessories may be dangerous and could expose you to the risk of electric shock, injury or other hazards

Refer any repairs to a qualified BOSS AUDIO SYSTEMS Service Center


Caution

Before Installing

To avoid potential shorts in the electrical system, be sure to disconnect the (-) battery cable before installation.

Use this unit with a 12-volt battery and negative grounding only. Failure to do so may result in a fire or malfunction.





Product Safety

It is against Federal and Local laws for video to be viewed by the driver while the vehicle is in motion. This video product was intended to be used with the parking brake safety feature. Video cannot be seen without the proper parking brake powered connection. Tampering or disabling this feature will void any and all warranty. Please check with a professional installer to have your product installed properly.

Important Note

Due to ongoing enhancements, example images on screens may slightly differ from actual product.



Caution

Images and Video

Watching video while driving is against Federal, State, and Local laws.

Drive safely, know and obey traffic rules. Watching this screen and making selections while driving can lead to a serious accident.

Check surroundings for safety while camera images are displayed.

Do not use features of this product while driving if it cannot be operated safely and legally in your location. Before operation of smartphone Apps accessible from this device, read safety instructions in your Owner's Manual. When using navigation Apps stay alert to observe real world conditions.

About this manual

To entirely understand how to properly use your new Boss product, it is recommended to read this entire user's manual, and keep it in a safe place for future reference.

-Read the entire manual

-Keep the manual

-Follow all instructions

-Clean with a dry cloth only

-Do not use or operate near water

-Do not defeat any safety features

California Residents (Proposition 65)

This product may contain chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

What comes in the box

Hardware

- Qty 1 BE9ACP
- Qty 1 Rubber Gromet
- Qty 1 Hex Bolt
- Qty 1 Hex Nut
- Qty 8 Screw M5x6


Qty 1	Tapping Screw 5X18 B/A
Qty 1	Tapping Screw 5X18 B/A

- Qty 1 Spring Washer
- Qty 2 Plain Washer
- Qty 2 Key
- Qty 1 Mounting Bracket


Qty 2 Brackets

Connections

- Qty 1 Power/Harness
- Qty 1 Hands-free Micro



Front Detail



1.MENU

Touch to return to the home menu, or previous source.

2.VIRTUAL ASSISTANT

Touch to command

3.TURN ON/OFF&VOLUME UP/DOWN

Long touch to turn ON/OFF the unit.Short touch to activate the MUTE
Function and silence the audio output.Touch again to restore sound.
Rotate to adjust the output volume UP or DOWN.

4.MODE

Touch to select system mode.


5.BAND


Touch to For radio band conversion between FM/AM

6.RESET KEY

The bottom hole is the reset button


Rear Detail






Unit Installation

THE UNIT IS INSTALLED TO BE AN ANTI-THEFT ONE. THE CHASSIS OF THE UNIT WEARS A SLIDING METAL HOUSING. PLEASE DO THE CONNECTION OF THE POWER, SPEAKERS AND ANTENNA ACCORDING TO THE REQUIREMENT OF THE INSTRUCTION BOOK, THEN INSTALL THE SLIDING METAL HOUSING IN THE CAR AS FOLLOWS.





Operation instruction




Basic Product Operation —— CAUTION!

Display screen removal





Using and Caring for the Touchscreen



Use:

This head unit utilizes a Capacitive Touchscreen, the same type that is used on high-end mobile devices. It should be used for and cared for like that type of device. As with all capacitive type technology, if your fingers are wet or sweaty, it will not function properly.

Do not allow any sharp objects to come in contact with the screen glass.

Care and Cleaning:

To clean the screen, use a dry microfiber type cloth to clean. Do not use ammonia, window cleaner, or any other type of household chemicals to clean the screen. Abrasives should not be used at all.

Product Setup (Date & Time)


Setup Option A: CarPlay Method

Connect your Apple [®] device using a Lightning[®] cable*. The CarPlay USB port must be used.


This will automatically setup the time and date.

User must set Time Zone manually.

Default is Pacific Time Zone



Setup Option B: Date and Time



Date & Time

Additional Setup

General > Language Audio > EQ, Other Audio Settings Display > Illumination, Brightness

Navigating the Menus **Android Auto** 06:08m Media ☆ uso Camera 🖒 CAMERA 12:15^{AM} 0 VT Music **None** A Gregory James Podcasts Celifornia Audio Show 2014 Read Notes Berinder CHECK YOUR CABLE CONNECTIONS AND MAKE SURE YOUR CAMERA IS CONNECTED AND POWERED ON Catendar NO SIGNAL DETECTED Weather Spasily. (J) Waze E, ÞI Home \bigcirc .ul 🛄 🛞 11:4. PM BOSS / ELTTE CarPlay EQ 87 n2:07** 0.0 Д 10-Streaming Nove Playing **8**20 B 27 0 Apple CarPlay Android Auto USB Camera Ω * 000 KT) ্ৰি Handsfree AV In 4 Tuner Settings Tuner Hands-free AV IN ☆Tuner 12:08 ^ ANDSFREE .al 🗖 🕃 12:06PM AV INPUT all 🖚 🛛 11:46au SETTINGS 12:21 🚧 🔅 General Language () 15 CHECK YOUR CABLE CONNECTIONS AND MAKE SURE YOUR VIDEO IS CONNECTED FA Time Zone 104.30 Ø Date & Time Daylight Saving Time 8 (7) 🕕 Dal Syseem Tone Power OFF Delay Camera

Apple CarPlay

Using CarPlay

(i) Note

Apple CarPlay usage is limited while driving.

Functions, contents, and usability is determined by the App provider(s).

Controls will vary with each App that is available for CarPlay.

For more details visit:

http://www.apple.com/ios/carplay

Familiarize yourself with your Local and State laws regarding mobile devices.

Certain functions of an iPhone might be prohibited and or illegal while driving in your location.

When in doubt, park the vehicle and engage the parking brake first before performing the function(s).

Connecting to CarPlay USB Port

- Connect the CarPlay compatible device via LIGHTING
 [®] cable (not included).
- 2. The iPhone will load the CarPlay function.
- 3. On the display, the CarPlay will illuminate green, touch it to enter the CarPlay menu.
- 4. To return to the product Home menu,




(\mathbf{i}) note

The product's Bluetooth will turn OFF automatically when CarPlay is in use. Hands-free phoning will function through the CarPlay feature.

When using CarPlay, there is no need to pair your iPhone, the USB cable connected through the USB Port (1) will enable this feature.

If other devices are connected via Bluetooth, they will be disconnected for the duration of CarPlay use.

Gestures & Control



Other gestures and controls might differ on each App.

i) NOTE

Volume control is handled exclusively by the product.

Apple CarPlay

Using CarPlay

CarPlay Display Setup

1. Using your iPhone:

Settings > General > CarPlay

2. Touch and Hold each App icon to move.

To remove an App, Touch 🦲



Only Apps with the icon can be removed from CarPlay. Only Apps with the icon can be added in carplay.



How to Disable Apps

1. Using your iPhone:

Settings > Notifications > App to Disable



Android Auto

Using Android Auto

(\mathbf{i}) Note

Android Auto usage is limited while driving.

Functions, contents, and usability is determined by the App provider(s).

Controls will vary with each App that is available for Android Auto.

For more details visit:

https://www.android.com/auto/

Familiarize yourself with your Local and State laws regarding mobile devices.

Certain functions of the mobile device might be prohibited and or illegal while driving in your location.

When in doubt, park the vehicle and engage the parking brake first before performing the function(s).

To complete the setup properly, the Parking Brake status wire must be connected.

For your safety, the setup process **MUST** be accomplished while the vehicle is **Parked and Parking Brake Engaged**.

Android Auto App

1. For Android 9.0 or earlier, download and install the Android Auto app from Google Play. For smartphone with Android 10.0 or later, plug in your phone and follow the prompts on your phone to accept the permissions that Android Auto requires



Minimum Requirements:

Android 5.0

For a list of compatible devices:

https://www.android.com/auto/

Updating Related Apps

1. During the st start up and setup of the Android Auto app, the Maps, Music, Google apps will install/update automatically.

Connecting to Android Auto USB Port

- Connect the Android compatible device via the appropriate USB cable (not included).
- 2. The Android device will load the Android Auto function.
- 3. Bluetooth will connect automatically when the setup is completed.

Android Auto Permissions Permissions

Several features can be allowed or denied access to customize your usability of the product.

The access can always be modified in Settings on the Android device.

Bluetooth®

Setup & Connection

Hands-Free Menu



CarPlay or Android Auto must not be active. If being used, disconnect the device to start Bluetooth.

Compatibility with all mobile devices is not guaranteed. Please read through the user's guide of the mobile device.

For your safety, the setup process should be accomplished while the vehicle is parked and parking brake engaged.

First time Pairing

Using your phone, media or other Bluetooth device, try to connect to this headunit.

Mobile Device: Search for **BOSS AUDIO BE9ACP**

iOS Devices: Settings > Bluetooth

Android Devices: **Settings > Connections >** Bluetooth

A passcode is generated and will display on both the head unit and mobile device for secure pairing.



Every time the product is powered ON, the mobile device will automatically connect if within range.

(\mathbf{i}) note

Once paired and connected, the device list will display the available Bluetooth profiles.

iphone Connected HFP A2DP

Phonebook and History

To Download Phonebook: 1. Touch Contact > Download

To Download History 1. Touch History > Download

Device Status

Battery and Cellular Strength is displayed on the top right of the Home menu.

GATT Profile support is required on the mobile device.



Bluetooth®

Hands-Free Calling Making & Receiving Calls 1. Dialing from the dial pad Touch Contact To make call 2. Contacts Touch the contact name 3. History Choose the name, then To End a call Touch To Mute a call Touch Dial pad To use the dial pad while on a call Touch 📵 **Searching History** Swipe Up or Down to search

History



3. Missed Call

Private Mode



2. Enter the Contact Name, then OK

21

Connection: ON Auto Connect: ON Auto Answer: OFF Device Name: BOSS AUDIO BE9ACP Clear Records

Bluetooth®

Audio


Audio Streaming

To play media through Bluetooth, the mobile device must be **Paired and Connected** to the BE9ACP



The music will play automatically.

Track Control



(i) Note

For best performance, your mobile device volume setting should be set to maximum.

All volume adjustments for the system should be controlled from the product.

The unit will recall the last volume setting on your mobile device every time is connects.

Formats

Playback is supported from the mobile device with any format it can play.

Audio will only be played by the product.

Video cannot be viewed on the unit.

Switching Media



Available sources will display (Bluetooth and USB)

(i) Note

USB source will only be displayed if a USB drive is inserted and has playable media.

Display

Track info will be displayed when available.

Track, Album and Artist.

Album art is not supported via Bluetooth playback.

Media

USE

USB Playback



The music will play automatically.

Audio Control

- 1. Play/Pause ▷ 📗
- 2. Track Fwd / Rev 🛛 🖂
- 3. Repeat ALL
- 4. Repeat One
- 5. Random 💢

5. Rotate

Video Control

3. Repeat All

4. Repeat one

Photo Control

1. Play/Pause > 📗

3. Repeat All

4. Repeat One

5. SETUP

1. Play/Pause >

2. Track Forward/Backward

D

2. Track Forward/Backward

0

203

(i) Note

If there are other files in the USB, music files will play first.

Navigating Menu



WARNING

Watching videos or photos while driving is against Federal ,State, and Local laws.

Do not use features of this product if it cannot be operated safely and legally in your **location.**

(i) Note

Review the connections of this product, to properly integrate the parking brake wire to the vehicle.

Video and or photos cannot be viewed while **driving. The vehicle must be stationary and** the parking brake applied to enable viewing.



Radio

AM/ FM

Controls



Tuning

To search for stations: Search Touch and Hold


Manual Seek Touch < >

Auto Search & Store: Touch 🛞

(i) Note

RBDS info (if available) and currently tuned station will display on the radio icon in the home screen

Not all stations will have or display RBDS info.



24

Touch FM to switch bands

To change radio settings Touch 👸

Favorites and Presets Settings Favorites Touch 🗙 Favorite Set

To remove a favorite, Touch **Browsing Favorites** Touch

87.50



Changing Presets

To list all Stored Stations

Touch

Stereo/Mono

To turn on/off stereo when receiving a stereo signal,

Touch OD

LOC/DX

To select Local or Distant broadcasting stations,

Touch (())

AV In/Camera

External Source

Playback



Media must be controlled from the external device.

Track functions are not controlled from the product.

Images may appear reversed

Do not use features of this product if it cannot be operated safely and legally in your **location.**

Rear View

The rear view camera can by displayed on demand.



(i) Note

To adjust the volume level properly, the carry-in device volume should be set between 50 % - 75%. The volume level should remain at **that level for the remainder of the time it is** connected to the product.

Never rely solely on the rear view camera; always check your surroundings before proceeding. If the user opens the SETTINGS interface and turn on both FRONT CAMERA and REAR CAMERA functions, you can choose REAR CAMERA and FRONT CAMERA casually.



To return to the Home screen



Reverse View

When the vehicle is put into reverse gear, the camera will display the image on the screen.



Rear View Delay

Due to varying vehicle configurations, the rear view trigger can be delayed to best suit the vehicle.

Default setting: 0 Sec Delay

(i) Note

The rear view camera will still function normally, if the product is in standby mode

Settings

General

System Language

Touch to change

English (Default), Spanish

(\mathbf{i}) Note

CarPlay is independent of the system language setting.

Time Zone

Adjust to correctly display time

Default Setting: (GMT-08:00) Pacific Time (US&Canada)

Date & Time

24H Mode



Auto Adjust Daylight Saving



i Note

If using an CarPlay, the iPhone will automatically set date & time. Time Zone needs to be adjusted manually.

System Tone



Power Off Delay

Some vehicles during crank to start will interrupt the accessory power.

If the product re-boots during crank to start, Turn **ON** delay

The delay can select 1, 2 or 3 sec.

Default Setting: OFF

i) Note

Power Off Delay **ON** will also delay when the vehicle is turned OFF.

This might affect hands-free functionality during a call.

Factory Settings

To restore settings to default:




Will restore all settings to factory defaults. All settings and presets will be lost.

Setting

Audio

EQ






(i) Note

The EQ can also be directly accessed while changing the volume. The volume display will show the EQ icon, you can touch to access the **Audio Settings**.



Preset EQ




Subwoofer

The level and filter can be adjusted for the Sub pre-amp output.

Level, 1-14 dB Swipe

Filter: 50Hz, 80 Hz, 120 Hz, 160 Hz Touch **+/-** Subwoofer Frequency

Loudness





Internal Amp

To reduce the possibility of noise entering the signal chain when utilizing the audio pre-amp outputs, the internal amp can be turned OFF



Volume

Settings are for default volumes for Main(Radio, Media), Hands-free(BT Ring, BT Talking), Apple CarPlay/Android Auto (Navi, Voice).

Source Level

The source mode(Radio, USB, BT Audio, AV Input, Apple carplay, Andriod Auto) gain control.

Settings

Display

Illumination Control

Touch OFF ON

When the vehicle lights are on, the products illumination can be customized for night use.

Gamma



Gamma can be adjusted for both day and night settings.

Screen Brightness



LED Touch Buttons

Panel Light Touch

Six preset colors can be chosen for Touch buttons, or chose below...





Will cycle through all colors on LED touch **buttons.**

Default Setting: ON

UI settings

Wall paper

Touch to change

User can change the background picture by **inserting a USB with photos.**

Background Brightness

Swipe



(i) Note

Bluetooth will turn **OFF automatically when** CarPlay is in use. If other devices are connected via Bluetooth, they will be **disconnected for the duration of CarPlay use.**

Bluetooth





Auto connects to the device when the product is powered ON

Default Setting: ON

Auto Answer



Auto answers when there is an incoming call. Default Setting: OFF

Settings

Bluetooth

Device Name BOSS AUDIO BE9ACP

Rear Camera input

Turn on if you have a rear view camera, turn off if you have not.

Front Camera Input


Turn on if you have a front view camera, turn off if you have not.

Parking Assist guide

Turn off if your rear view camera have parking assist guide, turn on if you have not.

Parking Assist guide Adjust

You can adjust parking assist guide



Camera

Rear View Delay

0 Sec (Default), 0.1 Sec, 0.5 Sec, 1 Sec, 2 Sec When switching from Park to Drive, or vice versa, the camera should not trigger on the display.

Sensitivity should be adjusted to trigger only on reverse gear selector.

Region



Default Setting: USA 2

US Tuner Spacing: FM (200 KHz), AM (10 KHz) European Spacing: FM (50 KHz), AM (9 KHz)

RBDS, Radio Broadcast Data System Touch ရက်

Default Setting: ON

Allows data from the radio station to be displayed on the product.

RBDS, Cont'd

Not all stations will broadcast information to display.

AF (Alternative Frequency)



When **On**, the tuner will automatically locate the same tuning program on other stations and select the strongest signal of those being broadcast.

Default Setting: OFF

TA (Traffic Announcement)



The radio will automatically tune in to traffic information broadcasts while receiving FM broadcasts playing media.

Default Setting: OFF


29

Radio


Power/SWC

It is recommended to have the product installed by a certified installation professional.

Before installation, or wiring connections, disconnect the negative (-) battery terminal to prevent damage to the product, and/or possible injury.




Remote Out is 500 mA max output rating. If several amplifiers are to be used, it is recommended to use a relay for the Remote Out trigger.



Blue/White, Rem. Output(+12v, 500 mA)

(i) Note

Unused input/output wires need be insulated with tape, heat shrink, or crimp connectors. **Never use wire nuts.**



Location to plug in

(i) Note

A separate interface might be needed for your **vehicle application. It is recommend that you** consult with a professional installer.

(i) Note

When replacing the fuse, always do so with the same type and value (**15** A).

Speakers A CAUTION Do not chassis ground any speaker wire leads. 0000 Only use 4-8 **Ω** Speakers Do not use 1-3 **Ω** Speakers 0 0 CAUTION \mathbb{A} Do not bridge any of the channels, they are Rear Right (Ch. 4) Rear Left (Ch. 3) only to be wired in stereo mode. Purple (+) Location to plug in Green (+) (i) Note Purple/Black (-) Green/Black (-) Unused speaker wires need be insulated with tape, heat shrink, or crimp connectors. Never use wire nuts. If the speaker outputs are not used, turn Off Front Right (Ch. 2) Front Left (Ch. 1) the internal amp to reduce the possibility of Gray (+) White (+) noise entering the signal chain. Gray/Black (-) White/Black (-)

(i) Note

Observe speaker polarity when making **connections.**


Audio Pre-amp/AV IN/ Radio



Subwoofer Pre-amp is a non-fading mono output.

(i) Note


Always run signal wires away from power cables to reduce the possibility of noise.



Pre-Amp Output A/V Input AM/FM Antenna

(\mathbf{i}) Note

If pre-amp outputs are being used exclusively, turn **Off** the internal amp of the product, to reduce the possibility of noise entering the signal chain.






Camera/USB/MIC



Never rely solely on the rear view camera; always check your surroundings before proceeding.

Images may appear reversed

Do not use a feature of this product if it cannot be operated safely and legally in your **location**.



Parking Brake



Improper connection or use of the parking brake status wire, (i.e. defeating the safety feature) violates Federal, State, and Local laws. This may lead to injury, property damage, and/or death.

Watching videos or photos while driving is against Federal , State, and Local laws.

(\mathbf{i}) Note


For Andoird Auto setup, the parking brake status wire **MUST** be connected.

(\mathbf{i})

Note

Review the connections of this product, to properly integrate the parking brake wire to the vehicle.

Video and or photos cannot be viewed while **driving. The vehicle must be stationary and** the parking brake applied to enable viewing.





Power/Speaker/SWC/Harness

(i) Note

The parking brake input needs to be connected to the power side of the parking brake.

(i) Note

Every vehicle has a different type of parking **brake connection; consult a certified** professional installer.

34

Lt. Green, Parking Brake Input

Hands-free Mic

Placement

Every vehicle will perform differently due to layout, interior materials, etc...


The **Red** shaded areas are the recommended **locations for best microphone performance**.

Items to look for before placement:

- 1. Do not place in front of air vents.
- 2. If the vehicle has tweeters placed on sail panels, do **NOT** locate the mic on steering column area.
- 3. Front of mic must not be blocked.
- 4. Mic should be firmly attached to mounting location.
- 5. Do not cover the grille openings surrounding the mic.
- 6. To avoid excessive wind noise, do not place near the sunroof opening



Run microphone wire where it will **NOT impede the operation of any safety items,** i.e. Airbags, Knee Airbags, etc...



Troubleshooting

No Sound	Internal amplifier is off	
	internarampiner is on	Go to Settings > Audio > Internal Amp ON
	Product is muted	Touch the volume.
	External ampli fi ers	Check the external amplifiers are on. Check the remote output wire has voltage
	Audio source	Change the audio source
Media Not Supported	Media on USB fl ash drive	Change the media format on the USB device Change the USB device
Bad Radio Reception	Radio area	Change the station
		Turn OFF AF and TA
		Turn OFF RBDS
	Antenna	Antenna output wire isn't connected
		Connect Antenna to product
Apple CarPlay/Anroid Auto will not start	Bad Lightning [®] /USB cable	Replace the cable
	Locked device	Device needs to be unlocked
	Not charged	Device needs to be powered ON for CarPlay/ Android Auto to function. Allow it to charge and power on.
	CarPlay/Android Auto frozen	Unplug the device, close all Apps and plug it in again.
Bluetooth	Not connecting to device	Make sure the device is within range.
		Devices' Bluetooth connection needs to be

Troubleshooting

Issues	Cause	Solution
Bluetooth	Not connecting to device	Go to Setting >Connection >Power ON Pair and Connect the device like new.
Hands-free call quality	Mobile device	Check cellular strength on mobile device. End call and redial number.
	Microphone	Microphone placement needs to be relocated Microphone needs to be firmly attached to location it's mounted on. Check to see if microphone is properly plugged in.
Unit is unresponsive	Processor has frozen	Press the RESET button on the front panel



If you have questions about this product:

Customer Service

805-751-4853

M-F 8:30a-5:00p (PST)

Tech Support: www.bossaudio.com/support/technical-support

© 2019 Boss Audio Systems

Specifications

General

Power Input
Nominal14.4 V DC
Current Consumption15A
Fuse Type15A
Dimensions (H x W x D)1.97"X7"X4.9"
Head Unit Weight
Operational Temperature4—158°F
Display
Screen Size
Aspect Ratio16 x 9
Resolution1024×600
Screen TypeTFT-LED Active Matrix
Audio
Max Power85 W x 4 Ch.
Acceptable Speaker Load4-8 Ω
Preset EQ5
EQ Bands, Adjustable10
JAZZ, HIPHOP, POP, ROCK, R&B
32, 63, 125, 250Hz, 500Hz
1KHz, 2KHz, 4KHz, 8KHz, 16KHz
EQ Boost/Cut± 6 dB

Audio Cont'd

Pre-amp Output	3 Pairs
Front4V, Fu	II-Range
Rear4V, Fu	ull-Range
Sub (Mono)	4V, LPF
Sub LPF50 Hz, 80 Hz, 120 Hz	, 160 Hz
Sub Level	+1-14dB

Radio Tuner

Freq. Range	87.5 MHz-108 MHz (FM)
Freq. Range	522 kHz-1710 kHz (AM)
USA 1 Range (FM)	100 kHz Spacing
USA 2 Range (FM)	200 kHz Spacing
Europe Range (FM)	50 kHz Spacing
RBDS	AF, TA

Apple CarPlay

iPhone Support	iPhone 5 or Newer
iOS	iOS 7.1 or Newer

Android Auto

Supported.....(5.0) Newer

USB

USB SpecUSB 2.0 (High-Speed)
USB Port 1: Carplay & Android Auto
Current Output 1.5A
USB Port 2: Media & 1.5A Charging
Current Output 1.5A
File SystemFAT32
Audio PlaybackWAV, MP3
Video PlaybackAVI, MKV, WMV
Picture PlaybackJPG, PNG, BMP
AND DETECTION OF THE CONTROL OF THE

*Not all listed compressed files guaranteed to **play due to different creation methods or file** contents.

Bluetooth®

Version	.v4.2+E.D.R.
Audio Codec	S.B.C.
Pro fi les	
HFP v1.6,A2DP v1.2,AVRCP v1.5,PE	3AP v1.1



BOSS Audio Systems 3451 Lunar Court • Oxnard, CA 93030 www.bossaudio.com 805-751-4853 Customer Service Tech Support: www.bossaudio.com/support



1020

IPhone* is a tradement of Apple Inc., registered in the U.S. and other countries. Apple Cer?Fey is a tradement of Apple Inc. BOSS Audio Systems is not effiliated with Apple Inc. The Bluetooth* word mark and logos are registered rademarks sowned by Bluetooth SIG, Inc. and any use of such marks by BOSS Audio Systems is under Icense. Other trademarks and bace names are those of their respective owned by

Android Auto is a trademark of Google LLC.

Use of the Apple CanPlay logo means that a vehicle user interface meets Apple performance standards. Apple is not responsible for the operation of this vehicle or its compliance with safety and regulatory standards. Please note that the use of this product with iPhone may affect wireless performance.

SPECIFICATIONS

Power Supply	DC 12v
Lens Angle (Deg.)	170°
TV System	NTSC
Video Output	1.0vp-p, 75Ω
S/N Ratio	< 48 dB
IP Rating	IP68
Operating Temp. (Deg. C)	-30°C ~ +70°C (RH 95% Max.)
White Balance	Auto
Minimum IIIumination	0.5 LUX
AGC	Auto
Resolution (TV Lines)	480
Electronic Shutter	1/60 (NTSC)
Effective Pixels	628 x 586

Above parameters can be modified without notification.

BOSS Audio Systems 3451 Lunar Court • Oxnard, CA 93030


www.bossaudio.com 800-999-1236 US Toll-free 805-751-4853 Customer Service

Tech Support: www.bossaudio.com/support/technical-support



USER'S MANUAL

REAR VIEW LICENSE PLATE MOUNT CAMERA FEATURING HIDDEN MOUNTING BRACKET




ALWAYS CHECK YOUR SURROUNDINGS BEFORE BACKING UP.



INSTALLATION

1. WIRE CONNECTION




Complete all required connections so that all lines are hidden in vehicle.

2. CAMERA INSTALLATION

Camera should be installed in the following configuration:

License Plate Frame Mount – Align camera frame with top-set of screw holes on license plate or license plate frame. Affix camera using license plate mount screws. See: (diagram 1)

Attention: The camera switch is controlled by reverse gear shift.





OPTIONAL

To remove the distance guide lines:

- 1. Turn the system OFF before proceeding
- Cut the white loop wire located at the connection points (camera end).
- 3. Insulate the wire, using tape or crimp connectors on both ends.
- 4. Reconnecting the wire will display the guide lines again.

To invert the camera image:

- 1. Turn the system OFF before proceeding
- 2. Cut the blue loop wire located at the connection points (camera end)
- 3. Insulate the wire, using tape or crimp connectors on both ends.
- 4. Reconnecting the wire will orient the image back to its original position.

TROUBLESHOOTING GUIDE

The following checklist might help to solve the problems when using this unit. Please double check to ensure connection and procedure of operation is done properly before using checklist.

PROBLEM	CAUSE/SOLUTION	
NO IMAGE	Check that power cable is securely connected. Check to ensure there is a good connection between video-in and monitor. Check that BVERSE GEAR is engaged. Check to ensure correct monitor setup.	
IMAGE BLURRING	Check for water/water stain or dust on camera lens. Clean camera lens	
IMAGE SHAKING	Check to insure camera is mounted and secured tightly.	
IMAGE SLANTED	Adjust camera mounting bracket	
NOTE: If problems persist – to disassemble or mo	consult nearest service dealer. DO NOT attempt dify unit.	