FURRION AURORA®

SMART 4K UHD FULL SHADE & PARTIAL SUN OUTDOOR TV

MODEL: FDUF**CSA, FDUP**CSA, FDUF**CSA-CA, FDUP**CSA-CA


QUICK START GUIDE



Model	Lippert Item No.	Model	Lippert Item No.	
FDUF43CSA	2021130705	FDUF55CSA	2021130707	
FDUP43CSA	2021130709	FDUP55CSA	2021130711	
FDUF43CSA-CA	2021135658	FDUF55CSA-CA	2021135660	
FDUP43CSA-CA	2021135662	FDUP55CSA-CA	2021135664	
FDUF50CSA	2021130706	FDUF65GSA	2021130708	
FDUP50CSA	2021130710	FDUP65CSA	2021130712	
FDUF50CSA-CA	2021135659	FDUF65CSA-CA	2021135661	
FDUP50CSA-CA	2021135663	FDUP65CSA-CA	2021135665	

This quick start guide will help you install and use the device properly. For further support and to download the complete user manual please visit **www.furrion.com/support**.


WHAT'S IN THE BOX




CONNECT

WARNING: Do not connect the power source before making connections. Open the cable access door to connect the cables.


NOTE: All external devices and cables shown in the diagram are for reference only and not included in the package.




Easy TV connect guide



CONNECT POWER



INSTALL REMOTE CONTROL BATTERY



NOTE: Protect the remote control from an accidental spill with the silicone sleeve provided. Do not immerse the remote control in water, or expose it to rain to prevent damaging it.


GETTING STARTED WITH webOS TV

Initial Setup

Press the **b** button on the control panel or on the remote control to turn on the TV, follow the on-screen instructions to finish the initial setup.

Quick Operating

The home screen will be displayed automatically when the TV is turned on. If not, press the $\widehat{\mathbf{h}}$ button on the remote control to pop up.



1 Launch search

Use $\triangle \nabla \triangleleft \triangleright$ buttons to navigate to and highlight Q, then press @ to start searching. You can search for a variety of content and information using the desired search terms.

NOTE: You must connect to the network to use the search feature. The search results may vary depending on the channel, region, network settings, and whether you have agreed to the terms and conditions.

Use home dashboard

Use $\triangle \nabla \triangleleft \triangleright$ buttons to navigate to e or press and hold the e button to select home dashboard. You can select or control a device (mobile, external device, Home IoT Devices, etc.) connected to the TV.

3 Switch the TV input used recently

Use $\triangle \nabla \triangleleft \triangleright$ buttons to navigate to and focus on \square , you can switch to the recently used TV input in the list quickly.

A Run or close a recently used app


Long-press the \bigcirc button or use $\triangle \nabla \triangleleft \triangleright$ buttons to navigate to and focus on 2. You can run or close a recently used app in the list of preview area.

5 Run, move or delete the apps installed

Use $\triangle \nabla \triangleleft \triangleright$ buttons to navigate to and focus on the app, it will provide the preview of the app at the top. You can check or run useful features of the app and recommended content on the preview without entering into the app.

NOTE: Some apps may not provide the preview.

Cable management



- After all connections are completed, lead all connecting cables downwards through the duct at the bottom of the cable access door.
- Leave a drip loop when cables enter the compartment. This will prevent water from dripping down the cord and possibly entering the door area.
- Close the door and tighten the thumb screws for the best weatherproof effect.

INSTALL

You are recommended to install the TV in an area shaded by trees, landscape and/or structures, or under a patio cover or gazebo.



Full Shade (Covered gazebos, patios, porches)

TV designed for fully shade outdoor spaces.

(Model: FDUF43CSA, FDUF50CSA, FDUF55CSA, FDUF65CSA, FDUF43CSA-CA, FDUF50CSA-CA, FDUF55CSA-CA, FDUF65CSA-CA)



Partial Sun (Pergolas, partially covered decks)


TV designed for partial sun exposure and brighter outdoor spaces. (Model: FDUP43CSA, FDUP50CSA, FDUP55CSA, FDUP65CSA, FDUP43CSA-CA, FDUP50CSA-CA, FDUP55CSA-CA, FDUP65CSA-CA)

NOTE: Connect all cables prior to mounting the TV on the wall or TV mount. The cable access door on the rear panel will be obstructed once the TV is mounted.

- Follow the installation guide supplied with the Wall-Mount Bracket when installing the TV.
- Choose an appropriate location and refer to the VESA pattern for mounting.

 It is recommended to contact a professional for installation and use at least two people to move or install the TV.

VESA MOUNTING PATTERN							
Model	Width (mm)	Height (mm)	Screw Size	Screw Quantity			
FDUF43CSA	200						
FDUP43CSA		200					
FDUF43CSA-CA	200	200					
FDUP43CSA-CA							
FDUF50CSA							
FDUP50CSA	200	100					
FDUF50CSA-CA	200	400					
FDUP50CSA-CA			MC * 15-222				
FDUF55CSA			M6 * 15mm	4			
FDUP55CSA							
FDUF65CSA							
FDUP65CSA	100	200					
FDUF55CSA-CA	400	200					
FDUP55CSA-CA							
FDUF65CSA-CA							
FDUP65CSA-CA							



FURRION


Furrion Innovation Center & Institute of Technology


- 52567 Independence Ct., Elkhart, IN 46514, USA Toll free:1-800-789-3341
- Email: support@furrion.com

©2007-2021 Furrion Ltd. Furrion® and the Furrion logo are trademarks licensed for use by Furrion Ltd. and registered in the U.S. and other countries.

For Patent Info: www.furrion.com/pages/patents

FURRION.COM





IG-FAV00068 V1.0

FURRION

WARRANTY MANUAL	ENGLISH (EN)
LIVRET DE GARANTIE	FRANÇAIS (FR)
MANUAL DE GARANTÍA	ESPAÑOL (ES)



Serial NO.: 111901701012200767 Made in China

Rev: 11-22-21 CCD-0004843

Congratulations on purchasing your new Furrion product. All Furrion products are made to strict quality standards. The details of this warranty are set out in the terms and conditions (see reverse) which supplement the authorized reseller or dealer's Terms and Conditions of Sale. Please visit www.furrion.com

LIMITED WARRANTY TERMS AND CONDITIONS

1. Furrion warrants that this product will be free from defects in workmanship and materials for a period of 12 months with parts and labor, except the products in the following table, from date of retail purchase, by the original end-use purchaser ("you") when delivered to you in new condition, in original packaging, from a Furrion authorized reseller or dealer and used in normal conditions. If a valid claim is made under warranty, then you will only be entitled to claim in accordance with paragraph 6 below.

Product Type	Warranty Period
AC/DC Power Centers	24 months
Air Conditioner	24 months
Arctic 12V 8 cu.ft. and 10 cu.ft. Refrigerators	24 months
Aurora Outdoor Televisions	24 months
eRove Portable Cooler	24 months
Gas Water Heater	24 months
Solar	24 months
Cordsets & Adapters, Power Inlets (RV, and Marine)	60 months

- The warranty only applies to Furrion products: with a valid serial number; used for consumer, private use and not for commercial or industrial use; and where you have validated the warranty in accordance with paragraph 4 below.
- 3. The warranty does not cover damage or loss: caused by poor, faulty or incorrect use, installation or maintenance; caused by accident (including force majeure or natural forces), misuse, negligence, abrasion, improper storage following delivery, rot and/or infestation following delivery, leaks (or similar incidents); occurring during shipment (even when Furrion arranged or paid for shipping): caused by failure to follow instructions in the owner's guide, damaged; caused by normal wear and tear; caused by maintenance, repairs or modifications other than those carried out by an authorized dealer; caused to the decorative surface of the product; caused to any data, software or information. This warranty also excludes claims based on any misrepresentations by the seller; or if this product's serial number has been altered, defaced, removed or rendered unidentifiable. This warranty is only valid in the country of purchase. Please see section 14 for specific product details.
- To validate the warranty, you must: (a) complete the registration via www.furrion.
 com, or by call center; and (b) register the warranty covering this product within 6
 months of the date of the bill of sale; and (c) have the original bill of sale to validate

warranty of this product.

- 5. If you require warranty service on this product, please cease using the product when a fault arises and contact us directly. You will have to present your original bill of sale to establish warranty coverage. Furrion's customer service can be reached at:
 - (i) For USA/Canada customers:

www.furrion.com

Email: support@furrion.com

Toll-free Number: +1 800 789 3341

- 6. Following the filing of a claim, Furrion will investigate the claim. If we believe there is a defect covered by the warranty, we will at our option either repair or replace the defective product (or part). It is Furrion's right to replace with new or refurbished product. If the product is part of an advanced exchange program, you may be required to provide a credit authorization during the claiming process.
- Please note in the event that no defect can be found, it is your responsibility to pay for the re-delivery of the replacement items. If a defect is found, Furrion will pay for the redelivery of the replacement items.
- 8. Installation of any repaired or replaced product will not be Furrion's responsibility.
- If you do not allow the authorized dealer to inspect the product which is the subject of the warranty claim, you will invalidate the warranty in respect of that claim.
- Any repaired Furrion product parts shall be guaranteed on the terms of this warranty for the unexpired portion of the warranty period only.
- 11. This warranty is subject to the jurisdiction of the courts of the State where you purchased this product, and any dispute or claim arising out of, or in connection with it or its subject matter, shall be governed by, and construed in accordance with the laws of that State.
- 12. In the event of any difference between this warranty and the provisions in any owner's manuals, warranty manuals, or packaging cartons, the terms of this warranty shall prevail to the fullest extent allowed by law.
- 13. THIS WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. FURRION SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IF FURRION CANNOT LAWFULLY DISCLAIM IMPLIED WARRANTIES UNDER THIS LIMITED WARRANTY, ALL SUCH WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. NO FURRION RESELLER, AGENT, OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION, EXTENSION, OR ADDITION TO THIS WARRANTY, FURRION IS NOT RESPONSIBLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPLACEMENT OF ANY EQUIPMENT OR PROPERTY, ANY COSTS OF RECOVERING, REPROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH FURRION PRODUCTS. FURRION'S TOTAL LIABILITY IS LIMITED TO THE REPAIR OR REPLACEMENT OF THIS PRODUCT PURSUANT TO THE TERMS OF THIS WARRANTY. SOME STATES DO NOT ALLOW THE

EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR EXCLUSIONS OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES OR CONDITIONS, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY BY STATE OR (WHERE APPLICABLE IN THE COUNTRIES WHERE FURRION HAS NON-US/CANADIAN AUTHORIZED DEALERS) COUNTRY. NO ACTION OR CLAIM TO ENFORCE THIS WARRANTY SHALL BE COMMENCED AFTER THE EXPIRATION OF THE WARRANTY PERIOD.

Félicitations pour l'achat de votre nouveau produit Furrion. Tous les produits Furrion sont fabriqués selon des normes de qualité rigoureuses. Les dispositions détaillées de la présente garantie sont énoncées dans les Conditions générales (voir au verso) qui complètent les Conditions générales de vente du revendeur ou du distributeur agréé. Veuillez consulter www.furrion.com

CONDITIONS GÉNÉRALES DE LA GARANTIE LIMITÉE

1. Furrion garantit un produit exempt de tout défaut dans la fabrication et dans les matériaux employés pour une période de 12 mois comprenant les pièces et la main d'œuvre, à l'exception des produits mentionnés dans le tableau suivant, à compter de la date d'achat au détail par l'acquéreur et utilisateur initial (« vous »), lorsqu'il vous est remis neuf et dans son emballage d'origine par un revendeur ou un distributeur agréé par Furrion et s'il est utilisé dans des conditions normales. Si une réclamation fondée est formulée au titre de la garantie, vous n'aurez de droits que ceux énoncés dans le paragraphe 6 ci-après.

Type de produit	Période de garantie	
Centrales d'alimentation CA/CC	24 mois	
Climatiseur	24 mois	
Réfrigérateur Arctic 12 V 8 pi.cu. et 10 pi. cu.	24 mois	
Téléviseurs d'extérieur Aurora	24 mois	
Glacière portable eRove	24 mois	
Chauffe-eau au gaz	24 mois	
Solaire	24 mois	
Câbles et adaptateurs, arrivées d'alimentation (pour véhicules récréatifs ou maritimes)	60 mois	

- La garantie ne s'applique qu'aux produits Furrion. Ces derniers doivent être dotés d'un numéro de série valide, être utilisés à des fins privées et non à des fins commerciales ou industrielles et avoir bénéficié d'une validation de garantie en accord avec celle décrite dans le paragraphe 4 ci-après.
- 3. La garantie ne couvre pas les dommages ou les pertes occasionné(e)s par une utilisation inappropriée, par une installation défectueuse ou par un défaut d'entretien,



FURRION

Important Safety Instructions
Consignes importantes sur la sécurité
Instrucciones de seguridad importantes





CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This 'bolt of lightning' indicates uninsulated material within your unit which may cause an electric shock. For the safety of everyone in your household, please do not remove product covering.



The 'exclamation mark' calls attention to features within the enclosed literature to prevent operating and maintenance problems.



WARNING: To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain / moisture or placed in the vicinity of objects filled with liquids (such as vases).

CAUTION: To prevent electric shock, fully insert the plug. For regions with polarized plugs: Please match wide blade to wide slot.


Important Safety Instructions

- 1. Read these instructions.
- 2. Keep these instructions.
- 3. Heed all warnings.
- 4. Follow all instructions.
- 5. Do not use this apparatus near water.
- 6. Clean only with a dry cloth.
- 7. Do not block any of the ventilation openings. Install in accordance with the manufacturer's instructions.
- 8. Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
- 9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
- 11. Only use attachments/accessories specified by the manufacturer.
- Use only with a cart, stand, tripod, bracket or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus to avoid injury from tip-over.



- 13. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as if the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, or when the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 15. Apparatus should not be exposed to dripping or splashing, and objects filled with liquids, such as vases, should not be placed on the apparatus.
- 16. An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an

- outside antenna system, extreme care should be taken to eliminate touching power lines or circuits as contact might be fatal.
- 17. Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- 18. Never push objects of any kind into this product through openings as they may touch short-out parts or dangerous voltage points that could result in a fire or electric shock. Never spill liquid of any kind on the product.
- 19. If an outside antenna is connected to the television equipment, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges. Section 810 of the National Electrical Code provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrodes.



- 20. NOTE TO CABLE/TV INSTALLER: This reminder is provided to call the CATV system installer's attention to Article 820-40 of the National Electric Code (U.S.A.). The code provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of the cable entry as practical.
- 21. When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or those that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.
- 22. Upon completion of any service or repairs to this unit, ask the service technician to perform safety checks to determine that the unit is in proper operating condition.
- 23. When you connect the product to other equipment, turn off the power and unplug from the wall outlet. Failure to do so may cause an electric shock and serious personal injury. Read the owner's manual of the other equipment carefully and follow the instructions when making any connections.
- 24. Sudden high volume may cause hearing or speaker damage. When you use headphones (if the unit is equipped with a headphone jack), keep the volume at a moderate level. If you use headphones continuously with high volume, you may suffer hearing damage.
- 25. Do not allow the product to output distorted sound for extended periods of time. This may cause speaker overheating and fire.
- 26. The socket-outlet must be installed near the unit and easily accessible.
- 27. The mains plug is used as the disconnect and shall remain readily operable.
- 28. Batteries (battery pack or installed batteries) should not be exposed to excessive heat such as direct sunlight, fire or other heat sources.
- 29. No naked flame sources, such as lighted candles, should be placed on the apparatus.
- 30. Attention should be drawn to the environmental aspects of battery disposal.
- 31. Use the apparatus in moderate climates.

CONDENSATION

Moisture will form in the operating section of the unit if the unit is brought from cool surroundings into a warm room or if the temperature of the room rises suddenly. When this happens the unit's performance will be impaired. To prevent this, let the unit stand in its new surroundings for about an hour before switching on,

or make sure the room temperature rises gradually.

Condensation may also form during the summer if the unit is exposed to the breeze from an air conditioner. In such cases, change the location of the unit.

How to Handle the LCD Panel

- Do not press hard or jolt the LCD panel. It may cause the LCD panel glass to break and injury may
 occur.
- If the LCD panel is broken, make absolutely sure you do not touch the liquid in the panel. This may
 cause skin inflammation.
- If the liquid gets in your mouth, immediately rinse and consult with your doctor. Also, if the liquid gets in your eyes or touches your skin, consult your doctor after rinsing for at least 15 minutes in clean water.

Possible Adverse Effects on LCD Panel: If a fixed (non-moving) pattern remains on the LCD panel for long periods of time, the image can become permanently engrained and cause subtle but permanent ghost images. This type of damage is NOT COVERED BY YOUR WARRANTY. Never leave your LCD panel on for long periods of time while it is displaying the following formats or images:

- Fixed images, such as stock tickers, video game patterns, TV station logos and websites.
- Special formats that do not use the entire screen. For example, viewing letterbox style (16:9) media on a normal (4:3) display (black bars at top and bottom of screen); or viewing normal style (4:3) media on a wide screen (16:9) display (black bars on left and right sides of screen).

The following symptoms are not signs of malfunction but technical limitation. Therefore we disclaim any responsibility for these symptoms.

- LCD panels are manufactured using an extremely high level of precision technology, however sometimes parts of the screen may be missing picture elements or have luminous spots. This is not a sign of a malfunction.
- Do not install the LCD panel near electronic equipment that produces electromagnetic waves. Some equipment placed too close to LCD may cause interference.
- Effect on infrared devices there may be interference while using infrared devices such as infrared cordless headphones.

Power source: This LED TV is designed to operate on 100~240 volt 50/60 Hz, AC current. Insert the power cord into a 100~240 volt 50/60 Hz outlet.

To prevent electric shock, do not use the LED TV's (polarized) plug with an extension cord, receptacle, or other outlet unless the blades and ground terminal can be fully inserted to prevent blade exposure.

Warning: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

Caution: Never remove the back cover of the LED TV as this can expose you to very high voltages and other hazards. If the TV does not operate properly, unplug the LED TV and call your authorized dealer or service center.

Adjust only those controls that are covered in the instructions, as improper changes or modifications not expressly approved by Furrion could void the user's warranty.

Internet security caution: It is strongly recommended for security purposes to connect your TV to the Internet via a router/modem that includes router functionality. Direct connection of your TV to the Internet may expose your TV to a security threat such as extraction or tampering of content or personal information.

Wireless Function of the unit (For TV with wireless function only)

- Do not operate this unit near medical equipment (pacemaker, etc.), as this may result in the malfunction of the medical equipment.
- Although this unit transmits/receives scrambled signals, be careful of unauthorised interception. We cannot be responsible for any trouble as a result.

COMPLIANCE

FCC Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment under FCC Rules.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

FCC Radio Frequency Interference Requirements (for UNII devices)

High power radars are allocated as primary users of the 5.25 to 5.35 GHz and 5.65 to 5.85 GHz bands. These radar stations can cause interference with and/or damage this device. This device cannot be colocated with any other transmitter.

FCC RF Radiation Exposure Statement

[For having wireless function (WLAN, Bluetooth,...)]

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be colocated or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20 cm (7.8 inches) between the radiator and your body. Users must follow the specific operating instructions for satisfying RF exposure compliance.

Industry Canada Statement

(For Canada)

[For having wireless function (WLAN, Bluetooth,...)]

This device complies with Industry Canada's applicable licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

IC Radiation Exposure Statement

(For Canada)

[For having wireless function (WLAN, Bluetooth,...)]

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm (7.8 inches) between the antenna & your body.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT, SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

(For Canada)

[For product having the wireless function using 5 GHz frequency bands]

- The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;
- For devices with detachable antenna(s), the maximum antenna gain permitted for devices in the bands 5250-5350 MHz and 5470-5725 MHz shall be such that the equipment still complies with the e.i.r.p. limit;
- For devices with detachable antenna(s), the maximum antenna gain permitted for devices in the band 5725-5850 MHz shall be such that the equipment still complies with the e.i.r.p. limits specified for point-to-point and non-point-topoint operation as appropriate; and
- The worst-case tilt angle(s) necessary to remain compliant with the e.i.r.p. elevation mask requirement set forth in Section 6.2.2(3) shall be clearly indicated.(devices operating in the band 5250-5350 MHz with a maximum e.i.r.p. greater than 200 mW)
- High-power radars are allocated as primary users (i.e. priority users) of the bands 5250–5350 MHz and 5650–5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

Safety Precautions


WARNING: Never place a television set in an unstable location. A television set may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

- Using cabinets or stands recommended by the manufacturer of the television set.
- Only using furniture that can safely support the television set.
- Ensuring the television set is not overhanging the edge of the supporting furniture.
- Not placing the television set on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the television set to a suitable support.
- Not placing the television set on cloth or other materials that may be located between the television set and supporting furniture.
- Educating children about the dangers of climbing on furniture to reach the television set or its controls.

If your existing television set is being retained and relocated, the same considerations as above should be applied.

The unit emits heat when in operation. Do not place any covers or blankets on the unit, this may cause overheating. Do not block ventilation holes, or set up near radiators. Do not place in direct sunlight. When placing on a shelf, leave 4 inches (10 cm) free space around the entire unit.





Notes when mounting the LED TV on the wall

If the unit is to be mounted on the wall, contact the retailer where you purchased the LED TV for advice, and have the equipment professionally installed. Incomplete or improper installation may cause injury to you and/or damage to the LED TV.

WARNING:

- Do not use this TV with wall mounts that allow the TV to tilt vertically. Vertical tilting wall mounts may
 cause structural damage to the TV.
- Use ONLY fixed or horizontal swiveling wall mounts with this TV.

Notice for TV Cabinet

If the unit is to be mounted on a cabinet smaller than the length of the unit, it could result in an unstable location. The unit may tumble over, making a risk of personal, possibly fatal injury. This would also damage the product seriously. Accordingly, Furrion accepts no responsibility or liability for any injuries or property damage resulting from the improper installation.

