


BREAK X1




QUICK START GUIDE


WHAT'S IN THE BOX




CARRYING STRAP



BREAK X1




TWO WIRELESS MICS




POWER CABLE


BUTTON



INTERFACES




HOMEPAGE



LIGHTING EFFECT



Microphone Indicator:

**CHARGING**
*LIGHT ON

**FULLY CHARGED**
*LIGHT OFF

Bass Boost Indicator:

**ON**

**OFF**


Charging Indicator:


**LOW BATTERY**
*SLOW FLASHING


**CHARGING**
*BREATHING

**FULLY CHARGED**
*OFF

Playback Mode Indicator:

**BLUETOOTH MODE**
*ON


**AUX MODE**
*ON

**LOCALPLAY MODE**
*ON



Bluetooth Indicator:

**PAIRING**
*FAST FLASHING

**CONNECTED**
*LIGHT ON




BLUETOOTH AUDIO



- 1 Press the **Bluetooth** button on the screen or press the playback mode button to switch into Bluetooth mode.


Bluetooth indicator light flashes fast.

- 2 Open the Bluetooth settings on your device and pair with 'IKARAO X1-XXXX'




Light on when connected successfully.


- 3 Press the Bluetooth button to disconnect




LOCAL AUDIO




1 Insert a USB with audio/video files



2 Click **Yes** on the screen prompt to enter the local media player




- 3 If you accidentally click **NO**,
re-enter the local media player by selecting **LOCAL MEDIA** .




NOTE: Local Media Player auto-loads .LRC lyrics from the same directory as audio files.


WI-FI AUDIO



1 Click **Settings**



2 Connect Your Wlan




NOTE: After connecting to Wi-Fi, use pre-installed apps to play music.


HDMI



1 Connect using HDMI cable




2 Select the HDMI input source to confirm connection




MICROPHONES



- 1 Hold the power button for 2 seconds to turn on.
Then the mic auto-pairs with the speaker.




- 2 Use buttons to switch effects, adjust volume, and play/pause.




NOTE: Don't point the mic at the speaker to avoid interference.

Two operation of mic will differ due to the version difference.(change mic effect*1, skip forward >2S)

- 4 Switch microphone sound via speaker buttons or **Mic Effect** in the software.




- 5 Click **Mic Settings** or **Custom** to enter custom sound mode and adjust Reverb, Treble, and Bass to your preference.




Enable vocal priority by clicking the **Music Ducking** button during speech.

SPEAKER CHARGING




1 Charging with the included power cable.




2

-  **LOW BATTERY**
*SLOW FLASHING
-  **CHARGING**
*BREATHING
-  **FULLY CHARGED**
*OFF




NOTE: The included power cable supports 100V-240V.

MICROPHONES CHARGING




Tap the microphone into the storage to begin charging.


NOTE: Microphone has a 30-hour usage duration with a 5-hour full charge time.




SOFTWARE UPDATE



1 Click **Settings**



2 Click **Detect New Version** on **About**




NOTE: Ensure speaker power is above 50% or plugged in.

CUSTOMER SERVICE



1 Click **Service**



2 Fill in your information

Ikarao Service

If you have any suggestions of this product kindly leave your precious advice here, and your feedback will encourage us improve our product preferably.

way 1 :



way 2 :

Model Number


Tel

Email

Question or Suggestion




USE CARRYING STRAP

1 Take out Carrying Strap




Carrying Strap


2 Buckle up Carrying Strap




NOTE: Please fasten the strap to ensure your speaker can be carried safely.



USE SPEAKER TRIPOD STAND




- 1 Extend the speaker stand and find the 35mm mount hole on the bottom of the Break X1



NOTE: The Speaker Tripod Stand requires a separate purchase.

- 2 Place the speaker securely on the stand. For safety, it is recommended to have two people.



IMPORTANT SAFETY INFORMATION

Safety Instructions Before Using the Machine:

- 1 Please read and retain this user manual.
- 2 Do not block the speaker's ventilation openings or sound channels with objects.
- 3 Avoid using the machine at high volumes for prolonged periods to prevent damage.
- 4 Use compliant accessories, internal batteries must not be removed or replaced by the end user.
- 5 The operating temperature should be between 0°C and 40°C.
- 6 Do not expose the device to damp or high-temperature environments such as puddles, sunlight, or open flames to avoid the risk of electric shock or explosion.
- 7 Unplug the machine during thunderstorms or if it will not be used for an extended period.
- 8 Do not forcibly insert a TF card or SD card into the slot. Insert the card in the correct sequence to avoid malfunction.
- 9 Do not use any corrosive or oily cleaners to clean the machine.
- 10 To maintain the machine's performance and battery life, fully charge it at least once every three months.
- 11 Note 5G band (W52) indoor use only.



CERTIFICATION AND COMPLIANCE



FCC ID:
2BCRN-BREAKX1A
IC:
32795-BREAKX1A

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Radiation Exposure Statement(Only for speaker)

This equipment complies with FCC radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiation & your body.



Dongguan Aika Electronic Technology Co., Ltd. declares that this product is in compliance with Directives 2014/53EU and all other applicable EU directive requirements. The complete declaration of conformity can be found at: www.ikarao.com




The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Dongguan Aika Electronic Technology Co., Ltd. is under license. Other trademarks and trade names are those of their respective owners.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Follow local rules and never dispose of the product and rechargeable batteries with normal household waste. Correct disposal of old products and rechargeable batteries helps prevent negative consequences for the environment and human health.

For FAQs and more information, please visit

WWW.IKARAO.COM/PAGES/SUPPORT



@ikaraoofficial @IKARAO



@IKARAO



@IKARAO



@IKARAO



@ikaraoofficial